

SERVICE BULLETIN #4003 - JUNE, 1984

TO: ALL HARMAN KARDON WARRANTY STATIONS

MODEL: CD391/CD491 CASSETTE DECKS


SUBJECT: PART NUMBERS FOR CASSETTE MECHANISM

The Service Manuals for models CD391 No. 68A and CD491 No. 66A did not indicate individual part numbers for the head base assembly, the reel motor assembly or the reel table assembly.

Indicated below are the new reference numbers and part numbers.

Ref.No.	Description	Part Number	
		Model CD391	Model CD491
502	Head Base Assembly	SIE0203202	SID0200404
503A	Reel Plate Assembly	KGE015114	KGE015114
503B	Reel Motor Assembly	KGE015115	KGE015115
541	Record/Playback Head	5874-3320	5874-1331
542	Erase Head	5873-1225	5873-1225
543	Screw (+) (2x4 mm)	SEE3054501	SEE3054501
544	Screw (+) (2x10 mm)	KGE103216	KGE103216

Page 19



Page 19

